






Setup instructions for production logging with GTB-700 microinverter

<p>1. Download the Smart Life mobile app by scanning the below code or following this link: https://e.tuya.com/smartlife</p>	<p>2. Launch the Smart Life app on your phone and click Register to create an account.</p>	<p>3. Click on the plus sign in the upper right corner to add a new device.</p>	<p>4. Click to manually add the “Socket (Wi-Fi)” device type under the “Electrician” tab.</p>	<p>5. Specify the local wireless network and its password, to which the microinverter will connect. Click next.</p>
				
<p>6. Turn on AC power to the microinverter. Then press and hold the red WIFI button for 5 seconds. The blue LED will start blinking rapidly to indicate it is ready for connection.</p>	<p>7. Click to add device. Wait for connection and then click done. If connection does not complete Wi-Fi signal may be too weak.</p>	<p>8. Click on the added microinverter from the home screen.</p>	<p>9. Click the “Electric” tab on the bottom right to view current and historical production data.</p>	<p>10. Production data can be seen here. Go back to step 3 to add another microinverter to your account.</p>
